USER'S GUIDE

Multi -use mixer
With digital effects, reproduction of Bluetooth media and functions

Directory

English Manual 1-6
Spanish Manual 7-12
German Manual 13-18
French Manual 19-24
Italian Manual 25-30
Dutch language Manual 31-36
Japanese manual 37-42

PRECAUTIONS

First read the content first before the operation is used

Save this manual in a safe place so you can consult it in the future.

⚠ WARNING

To avoid serious injuries caused by electric shock, short circuit, injuries, fires or other dangers, be sure to meet the following basic precautions. These precautions include, among others, the following situations:

Do not open

•The device does not contain parts that you can repair. Do not open the device or try to disassemble its internal parts or transform in any way. If an exception occurs, stop using it immediately and repair the qualified maintenance personnel.

WARNING ABOUT HUMIDITY

•Do not use the equipment to rain or use near the water and in a wet environment, or place the container with liquid (such as vase) on the equipment to prevent liquid from dripping into any opening. If the liquid device and other liquids are spilled in the device, cut the energy immediately, unplug all the product connection cables and then repair the equipment with qualified maintenance personnel.
•Do not insert the cable connection with wet hands.

Alarm

•Do not place flame objects on the device, such as candles. Burning objects can fall and cause fire.

When you realize any abnormal situation

•When one of the following problems occurs, immediately turn off the feed switch, unplug all product connection cables and then repair the qualified maintenance repair:
- Damage to power cable or plug.
- Excluding an unusual smell or smoke.
- Some objects fall on the device.
- The sound was suddenly interrupted during the use of the equipment.

•If the equipment falls or damages, turn off the feed switch immediately, unplug all product connection cables and repair the equipment for qualified maintenance personnel

⚠ WARNING

To avoid the injury, damage, equipment or loss of property that people can happen to others around them, be sure to meet the following basic precautions. These precautions include, among others, the following situations:

Placement

•Do not put the equipment in an unstable place, otherwise it can suddenly cause it to fall.
•Do not place the device in the that can be exposed to corrosive gases or salt containing salt. Otherwise, it can cause the corrosion.
•Before moving the device, be sure to disconnect all connected cables.

Connection

•Before connecting this device with other equipment, turn off the ignition switch of the other equipment. Before turning on or turning the ignition switch of the entire equipment, adjust the entire volume to the smallest.

Maintenance

•When cleaning this device, be sure to unplug all product connection cables.

Precautions

•Do not put your fingers or hands in any space or opening of the equipment.
•Avoid any spread or opening on the device, insert or fall into foreign objects (paper, plastic, metal, etc.). If this happens, turn off the feed immediately and then unplug all product connection cables. Then repair the equipment with qualified maintenance personnel.
•Do not place any liquid on this device or place heavy objects on it. When the operation button, the switch or the socket, avoid excessive force.
•Do not continue using speakers or headphones at high or uncomfortable volume levels for a long time, otherwise it can cause permanent auditory damage. If you find deaf or tinnitus, seek healing.

•The company will not answer any responsibility for the loss, loss of data or damage caused by the use or inappropriate transformation of the equipment without authorization.

Warning

To avoid damage to which this product, data or other components may be subject, pay attention to the following issues.

•Operation and maintenance

•Do not use this device near TV, radio, stereo equipment, mobile phones or other electronic devices. This can cause noise in the device itself and on television or radio near the device.To avoid deformation, unstable operation or damage to internal components, do not place this equipment in an environment with a large amount of dust, vibration, extreme or hot cold (such as direct sunlight, near the heating device or under the scorching car).

•To avoid deformation, unstable operation or damage to internal components, do not place this equipment in an environment with a large amount of dust, vibration, extreme or hot cold (such as direct sunlight, near the heating device or under the scorching car).

•Do not place ethylene, plastic or rubber objects on the machine, otherwise, the panel can be discolored.

•When cleaning the equipment, use soft cloth. Do not use coatings, solvents, cleaning liquids or chemical towels.

•The device can condense due to rapid changes in ambient temperature. For example, when the device moves from one place to other places, or when the air conditioning turns on or off, the use of this device will cause damage when the condensation occurs.
If there are reasons to believe that condensation can occur, place this equipment for several hours without turning on the energy until the condensation disappears completely.

•Do not establish any balance and attenuator in the maximum position. Otherwise, according to the specific state of he connected device, the speaker can be damaged by feedback.

•Do not apply oil, fat or contact cleaner for the thrust.

•If any auditory damage or tinnitus occurs, go to the doctor.

•When you turn on the CA feeding source of the audio system, you always turn on the power amplifier to avoid damaging the speaker.
Similarly, when extinguished the power, first turn off the power amplifier.

•When the device is not used, configure the switch in the waiting position.

•Interface

•The XLR interface must be carried out according to the figure below (standard IEC60268): needle 1: Earth wire, needle 2: Direct line (+) and needle 3: cold line (-).

Information

•About these instructions

•The illustrations shown in this manual are only for description.

•In the manual, if it does not specifically indicate, all the illustrations of the panel are based on the last panels.

•To facilitate its understanding of the content of the instruction manual, the company has translated English and Chinese expressions in a unified meaning according to the relevant standards of the current language of the world. However, due to professionalism, generality and particularity, certain content is still explained in English. If you have any questions, contact our customer service at any time.

Thanks for buying our product

Thank you for choosing this audio mixer. Read this manual carefully to completely understand this product and make sure it is used for a long time. After reading this manual, keep it correctly for future reference.

The main function

•Bluetooth XLR Multifunction entrance
•Incorporated with 256 type 24 bits DSP Parameter Adjustable sound: adjustable audio effect
•1 section equalizer channel
•12 - stage double level monitoring
•Pre Sound Image positioning, signal detection monitoring light
•Support Bluetooth Audio Receiver, 3 Stepping Effect, RCA connection
•Return return headphones and monitoring
•6V Phantom Power Source
•16 channel Stereo Input
•8 Channel Stereo Output

Connection instance


Wireless microphone, Microphone
Audio Frequency amplifier, Active speakers, Passive speakers, Power amplifier
Audio/microphone interface
DJ Mixer
Active speakers monitoring
Passive speakers monitoring
Power amplifier
Headphones
Mixer
Computer
Internet
Wired/wireless earphone
Wireless earphone
Wireless microphone
Wireless microphone
Wireless earphone
DVD machine,Karaoke/DTV machine
Microphone
Headphones
Computer
USB flash memory
USB flash memory
Computer
Headphones